

Important: Please read the instructions carefully and thoroughly before you begin your DIY installation process.

**For ADHESIVE FILM (All Buy products except Static Cling), please see below**  
**For NON-ADHESIVE FILM (Static Cling), please refer to the back page**

## TOOLS YOU NEED

- A spray bottle with liquid soap & a spray bottle with water : An empty and clean Windex bottle may work; to make the liquid soap solution put about 6-8 drops of very mild detergent or baby shampoo in a 32 oz. spray bottle filled with water
- A plastic card squeegee : As a substitute you may use a plastic paint scraper or an old credit card
- A few paper towels (clotton cloth preferred)
- A sharp retractable knife : Someone who can give extra hands would be very helpful

## 1. MEASURE AND CUT FILM

It is a good idea to start with small windows first especially when you are not experienced much. Measure the width and height of the glass surface and determine where you'd like the film keeping about a 1/16" margin between the window frame and film. The edges of film should not touch the window frame upon installation.

## 2. CLEAN THE WINDOW

It is very important to clean the area to which the film will be applied. Make sure that it is free from grease, dirt, lint and grime to ensure the film's adhesiveness.

## 3. WET THE WINDOW

With the spray bottle and liquid soap solution spray & fully wet window until beads of soapy water run down the glass. If the window becomes dry, rewet it completely before applying film. Don't try to apply in the direct hot sun as your solution will dry up pretty fast.

## 4. REMOVE THE LINER FROM THE FILM

Window film has 2 parts - the film and the clear liner. Peel away corner of the liner first by attaching two pieces of tape firmly to the front and back side of film's corner. Pull them apart to separate the little portion of liner and the film. Then wet/spray another part of window's surface or a different window's surface, have the liner side of film facing you, and cling the peeled corners of film on the newly wet surface. This will hold the film while you remove the rest of liner (or it is better to have someone hold the film while removing the liner). As you carefully peel the liner away, generously spray the liquid solution on the exposed adhesive sticky side of the film. Gently take the corners of film off the window.

## 5. APPLY THE WET FILM ON THE WET WINDOW

When liner is removed from the film, both window and film should be fully wet with soapy water. Place the adhesive side of the film gently on the glass. Handle the film carefully by holding corners to avoid wrinkles or finger prints. Once the film is applied on the window, move around the film for the right placement. If the film is stuck and not moving, you need to peel off the film a little and add more water spray on the window.

## 6. SQUEEGEE THE FILM

Now using the plastic squeegee move from the center out towards the edges to remove soapy water and air bubbles. Spraying water on the film's surface will make squeegeeing process easier. Cover the squeegee blade with paper towel to prevent any scratches during this process. Although all Buy window films have Scratch Resistance Coating, sharp plastic squeegee may leave scratch marks. You can remove large bubbles with the squeegee. Small bubbles smaller than 1/8" will disappear in a few days.

## 7. TRIM THE EDGES

By pressing the edge of the film to the window frame with your squeegee as a guide, trim the film with knife around the four edges.

## 8. CLEAN AND CURING

Clean the film with soapy water. It may take a few days to dry and completely stick to the glass.

### *For NON-ADHESIVE FILM (Static Cling)*

#### TOOLS YOU NEED

- A spray bottle with water : An empty and clean Windex bottle may work
- A plastic card squeegee : As a substitute you may use a plastic paint scraper or an old credit card
- A few paper towels (clotton cloth preferred)
- A sharp retractable knife : Someone who can give extra hands would be very helpful

#### INSTRUCTIONS

1. Measure and cut film according to the size of your window frame leaving a little bit of margin between your film and window.
2. Clean window glass.
3. Remove the back liner of film.
4. Spray the back of film with water.
5. Install film on glass and squeegee out the water.
6. Cut out any extra film with knife and squeegee the edges dry with a squeegee wrapped in paper towel.

#### Return Policy

You may return most new, unopened items within 30 days of delivery for a full refund. We will also pay the return shipping costs if the return is a result of our error (you received an incorrect or defective item, etc.). However, please be advised that any opened or failed item due to installation mistakes is not refundable.

You should expect to receive your refund within four weeks of giving your package to the return shipper; however, in many cases you will receive a refund more quickly. This time period includes the transit time for us to receive your return from the shipper (5 to 10 business days), the time it takes us to process your return once we receive it (3 to 5 business days), and the time it takes your bank to process our refund request (5 to 10 business days).

If you need to return an item, simply login to your account, view the order using the "Complete Orders" link under the My Account menu and click the Return Item(s) button. We will notify you via e-mail of your refund once we've received and processed the returned item.

For more information please check the Store Policy on our website at [www.buydecorativefilm.com](http://www.buydecorativefilm.com)